

4000

there must be no steel bars in the position where the expansion screws are installed; 3. The concrete must be completely dry before installation;